




FRAME AND CONSOLE PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0

UNDERCOUNTER
DISHWASHER



<https://whirlpooldishwasherusermanual.wordpress.com/>


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8535436	Literature Parts Instructions, Installation	4	3369529	Follower, Cam	14	3376405	Elbow, Harness
	3367007	Instructions, Installation (Supplement) (Locating Your Water Supply)	5	8535368	Timer	15	3400892	Screw,
	8535421	Guide, Energy	6	8271510	Cam	16	8269526	Cover, Control
	8535037	Guide, Use & Care	7	304231	Screw, 8-18 x 1/2	17		Knob, Timer
	3385497	Diagram, Wiring	8	9743028	Door Frame		8275308	Black
	677967	Do-It Yourself Manual	9	3380854	Bolt, Latch		8275309	White
2	8535383	Insert, Console	10	3369457	Lever, Latch	19		Panel, Front
	8535384	Black		3372231	Black		3379375	Black
	8269366	White	11	3369325	Switch, (2)		3379376	White
3		Switch, 5 Button	12	3368955	Pin, Switch (2)		9743581	Stainless
			13	8275123	Harness and Protector	20		Console (Includes Item 2)
							8535328	Black
							8535329	White
						21	3379671	Shield, Control Cover
						22	3373234	Bearing, Spring (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0

(Black) (White) (Stainless)




<https://whirlpoddishwasherusermanual.wordpress.com/>

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8528310	Inner Door (Includes Items 2 & 3)	4	8519606	Actuator Assembly	8	3368999	Spring (Draw Bar)
2	3376066	Latch, Detergent Dispenser (Includes Item 3)	5	8052027	Wet Agent, Dispenser	9	3385001	Lid Assembly
3	3369061	Snap, Detergent Dispenser (Includes Item 2)	6	3369000	Draw Bar (Upper Dispenser)	10	8066018	Spring, Lid
			7	8066017	Draw Bar (Lower Dispenser)	11	3372028	Pin (Lid Hinge)
						12	3371710	Screen, Vent
						13	3378134	Cap, Wet Agent
						15	3400815	Screw (8)
						16	3371569	Cover, Drip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0
(Black) (White) (Stainless)



<https://whirlpooldishwasherusermanual.wordpress.com/>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0

(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8533815	Tub and Support Assembly	17	304392	Screw, 8-18 x 1/2	35		Panel, Access (Includes Item 39)
2	8528831	Tub, Wheel Assembly (8)	20	8052018	Pad, Friction		3379917	Black
3	3368933	Runner (2)	21	8529303	Terminal Box		3379918	White
4	3374849	Leveler (2)	23	3370225	Screw		9744517	Stainless
5	3370389	Screw, Shoulder (2)	24	3369063	Relay	36	302868	Screw, 8-18 x 1/2 (4)
6	302819	Wheel (2)	25	304231	Screw	37	3369414	Hose, Inlet
7	343641	Screw, 10-16 x 1/2 (4)	26	3368928	Fuse, Thermal	38	371505	Clamp
8	3378149	Plate, Latch	28	3379383	Spring, Door (2)	39	3378123	Clip, Grounding
9	3374720	Screw	29	8318218	Housing, Float Switch	40	8531031	Sound Shield
10	3376927	Gasket	30	3369067	Switch, Float	41	300068	Cover Assembly, Terminal Box
11	3369322	Grate	31	8318219	Cover, Switch Housing	43	3374077	Drain Hose
12	8528862	Deflector (2)	32	8519552	Float	44	356138	Hose Clamp
13	8519827	Heater	33	717488	Nut	52	3379740	Support, Heater (3)
14	717273	Washer, Rubber (2)	34		Panel, Toe	53	3400014	Screw
15	8268548	Nut (2) (Heater Terminal)		3368942	Black	54	3378128	Washer
16	8283345	Water Valve		9742861	White	56	3369138	Screw, 8-18
						57	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

<https://whirlpooldishwasherusermanual.wordpress.com/>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP AND SPRAY ARM PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0


(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|--|---------|--|
| 1 | 3369037 | Grommet, Pump Seal |
| 2 | 3369015 | Pump & Motor Assembly |
| For Breakdown Of Pump Parts, Refer To Pump And Motor Parts Page. | | |
| 3 | 3369035 | Hose, Pump Inlet |
| 4 | 3400959 | Clamp |
| 5 | 8531963 | Support, Motor |
| 6 | 3369032 | Grommet, Motor Support |
| 7 | 3370856 | Pushnut, Motor Support |
| 8 | 3369038 | Washer, Grommet |
| 9 | 8268870 | Spray Arm, Assembly Lower |
| 10 | 8268883 | Nut, Pump Outlet |
| 11 | 3371745 | Support & Bearing Assembly (Includes Items: 13, 14 & 15) |
| 12 | 3369045 | Seal, Split Ring |
| 13 | 3369044 | Washer |
| 14 | 3371746 | Bearing |
| 15 | 3371744 | Shoulder Screw |
| 16 | 8520833 | Collector Assembly w/Check Valve |
| 17 | 8520841 | Funnel |
| 18 | 8520843 | Seal |
| 19 | 3369177 | Seal |
| 20 | 3369178 | Ball, Check-Valve |
| 21 | 371499 | Clamp, Hose |
| 22 | 8520842 | Hose, Collector |
| 23 | 3371634 | Washer, Curved |
| 24 | 3369181 | Screw 10-16, Hi-Lo (4) |




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP AND MOTOR PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0

(Black) (White) (Stainless)




<https://whirlpooldishwasherusermanual.wordpress.com/>

Illus. No.	Part No.	DESCRIPTION
1	3369011	Housing Assembly
2	3369031	Seal, Drain Cover
3	3369028	Diaphragm
4	3369029	Ring, Diaphragm
5	3369030	Cover, Drain Valve
6	3368921	Screw (4)
7	3369020	Seal Seat
8	3385557	Seal Head
9	3369013	Impeller & Bearing Assembly
10	3369012	Disk & Mount Assembly
11	8283457	Motor
12	3368922	Screw (3)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0
(Black) (White) (Stainless)



<https://whirlpooldishwasherusermanual.wordpress.com/>

Illus. No.	Part No.	DESCRIPTION
1	8539225	Dishrack, Lower
2	8268825	Tower, Protector
3	3385142	Bumper, Dishrack (2)
4	8268645	Wheel & Transport Assembly (4)
5	8268866	Basket, Silverware
6	3385089	Track, Dishrack (2)
7	8524581	Stop, Track (4)
8	8539222	Dishrack, Upper
9	8268852	Wheel & Axle Assembly (4)
11	8519550	Diffuser, Water

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: DU850SWPB0, DU850SWPQ0, DU850SWPS0
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>PAINT, TOUCH-UP (1 qt.)</u>			<u>ACCESSORY PARTS</u>		
	72017	White		799340	Black (Uncut)			Side Panel Kits:
	72032	Black		4392900	Biscuit			4317925 White
	4392899	Biscuit						4396188 Biscuit
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>			<u>DISHRACK REPAIR</u>					Door Spring Kit:
	285006	Superior Black		675576	Vinyl Touch-Up (Blue)			4318050 Heavy Duty
	350942	Primer (White)		676453	Vinyl Touch-Up (White)			
	4392901	Biscuit		676455	Vinyl Touch-Up (Grey)			

<https://whirlpooldishwasherusermanual.wordpress.com/>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST